




HONDA
One HEART.



SPECIFICATIONS

ENGINE

Engine Type: Liquid-Cooled, 4-Stroke, SOHC, eSP | Displacement: 150cc
Bore x Stroke: 58 x 57.9 mm | Max. Power: 10.9 kW / 6,250 rpm
Max. Torque: 13.8 Nm / 4,500 rpm | Transmission: Automatic
Clutch Type: Automatic Centrifugal, Dry | Final Drive: Belt

FUEL SYSTEM

Fuel Supply System: PGM-FI (Programmed Fuel Injection System)
Fuel Capacity: 15.0 liter | Compression Ratio: 10.4 : 1
(Fuel Consumption: 0.55 km/l (90 km/h) / 0.5 km/l)

ELECTRICAL SYSTEM

Starter: Electric | Headlight: LED | Taillight: LED
| Battery Capacity: 12 V / 5 AH

DIMENSION

L x W x H: 2,094 x 740 x 1,150 mm | Wheelbase: 1,360 mm
Ground Clearance: 145 mm | Curb Weight: 136 kg (ABS)
Seat Height: 799 mm

FRAME & CHASSIS

Frame Type: Steel, Underbone Type | Front Suspension Type: 33 mm
Telescopic Fork | Rear Suspension Type: Dual Damper Unit, Swing Arm with
5-Step Preload Adjuster | Front Tire Size: 100/80 - 16 M/C 50P (Tubeless)
| Rear Tire Size: 120/80 - 16 M/C 60P (Tubeless)

BRAKES

Front Brake Type: Disc Brake | Rear Brake Type: Disc Brake
Braking System: Antilock Braking System, 2-Channel
| Front Brake Spec: 2-Piston Calipers, 240 mm Disc
| Rear Brake Spec: 1-Piston Caliper, 240 mm Disc



CANDY LUSTER RED



PEARL JASMINE WHITE



POSEIDON BLACK METALLIC



MAT GALAXY BLACK METALLIC

*Models are shown in European type. Indonesian models may vary.



TIMELESS & ELEGANT DESIGN



LED Lighting System



ANTI-THEFT ALARM & Answer Back System



SMART KEY System



ABS & 16-INCH Wheel Size



HELM-IN Utility Box



REAR SUSPENSION With 5-Steps Preload Adjustment



#CARI_aman
santia motor

Carilah selalu helm, pasang tali pengikat dan bencangan secara benar.
Santia jajan dengan panjang dan sering tangan yang
dipanggang untuk keselamatan dan kenyamanan berkendara.
Pakai selalu panjang yang pas dan nyaman
serta gunakan sepatu untuk kestabilan saat kaki berputar.



Honda Customer Care
1-500-989
0811-9-500-989
customer@astra-honda.com

Follow Us:

welovehonda Indonesia
welovehonda
welovehonda_id
welovehonda Indonesia

www.astra-honda.com

Carilah Perawatan yang Benar

* Periksa tingkat pemakaian oli dan gunakan
satu oli AMO Oil.
* Periksa rem dan tekanan udara ban.
* Gunakan Honda Genuine Parts, sebab
nyalaan anti-rapoda motor Honda yang
diperbaiki akan oleh PT Astra Honda Motor.
* Lakukan perawatan standar di bengkel
bengkel resmi Honda (AMSS).

Dibantu oleh
AHM
PT Astra Honda Motor

